

Triac/0-10V/1-10V/Potentiometer/10V PWM 5 in 1 Dimmable led driver KVG-DWJ 300W

_

Whole Family

KVG-XXXXX-DWJ 12V/ 24VDC 30W 60W 80W 96W 100W 120W 150W 200W 300W





TYPE HI





■Features

·Output constant voltage

·UL, cUL listed, Type HL rated. FCC

·Universal AC input: 110-277VAC

.Power Factor: up to 0.99

·High efficiency: up to 92%

·Load: 10-100%

·Protection:short circuit/over loading/ Over temperature

·PWM output, does not change the color index

·Full protection metal case, for dry, damp, wet location

·Flicker-free

·Dimming function:

Phase dimming: work with forward phase /leading edge ,MLV and

Reverse phase /trailing edge ,ELV,TRIAC dimmers

0-10V dimming: 0-10V/1-10V/Potentiometer/10V PWM 4 in 1

· Dimming range: 0-100%

·Suitable for LED lighting and moving sign applications

Model		KVG-12300-DWJ	KVG-24300-DWJ
Certificates		UL, cUL listed, Type HL rated, FCC	
Output	DC Voltage	12V	24V
	Rated Current	25A	12.5A
	Rated Power	300W	300W
	Voltage Tolerance	±0.5V	
	Voltage Regulation	±0.5%	
	Load Regulation	±2%	±1%
Input	Voltage Range	110-277VAC	
	Frequency Range	47-63Hz	
	Power Factor (Typ.) @ full load	0.99@120VAC 0.97@277VAC	0.99@120VAC 0.95@277VAC
	THD (Typ.) @ full load	<20%	
	Efficiency (Typ.) @ full load	86% @120Vac 88%@277Vac	88% @120Vac 92%@277Vac
	AC Current (Max.)	3.4A@100Vac	
	Inrush Current (Typ.)	20A, 50%, 1.9ms @120Vac 35A, 50%, 1.9m,s @277Vac	
	Leakage current	<0.50mA	
Protection	Short Circuit	shut down o/p voltage, re-power on to recover after fault condition is removed	
	Over Loading	≤120% Hiccup mode,recovers automatically after fault condition is removed	
	Over temperature	100°C±10°C shut down o/p voltage, automatically recover after cooling.	
Environment	Working TEMP.	-40∼+60°C (see below derating curve)	
	Working Humidity	20∼90%RH, non-condensing	
	Storage TEMP. Humidity	-40∼+80℃,10∼95%RH	
	TEMP .coefficient	±0.03%/°C (0~50°C)	
	Vibration	10∼500Hz, 5G 10min./1 cycle,period for 60min. each along X,Y,Z axes	
Safety& EMC	Safety standards	UL8750+UL1310	
	Withstand voltage	I/P-O/P:1.88KVAC	
	Isolation resistance	I/P-O/P:100MΩ/500VDC/25℃/70%RH	




Triac/0-10V/1-10V/Potentiometer/10V PWM 5 in 1 Dimmable led driver

KVG-DWJ 300W


	EMC EMISSION	FCC Part 15 B	
others	Net. Weight	2.0Kg	
	Size	278*110*45mm (L*W*H)	
	packing	10PCS/CTN	
Notes	1. All parameters if NOT specially mentioned are measured at 120VAC input , rated load and 25℃ of ambient		
	temperature.		
	2. To extend the driver's using life ,please reduce the loading at lower input voltage.		

■ Derating Curve



%To extend their life, please refer to the Derating Curve and derate according to the temperature.

■ Mechanical Specification



Unite: mm

Tolerance: 0.5-2mm



Triac/0-10V/1-10V/Potentiometer/10V PWM 5 in 1 Dimmable led driver


KVG-DWJ 300W

- * Input wire Black and White to be connected to AC L and N ,Green wire go ground,
- **Output wire Red to LED Positive side (+), Black to LED Negative side (-).
- **Dimming cable DIM (+) Purple to 0/1-10V dimmer signal(+),DIM (-) Grey to 0/1-10V dimmer signal (-)
- **Please make sure your connect these correctly otherwise your product will not function correctly and could be damaged.
- *Note: Any other requests we can customized.


■ Connecting Diagram

***Using TRIAC/Phase cut dimming**

- 1. The Pulse-Width Modulation (PWM) of output voltage can be adjusted through input terminal of the AC phase line(L) by connection a phase /Triac dimmer of lighting system.
- 2. Work with forward phase /leading edge ,MLV and reverse phase /trailing edge ,ELV,TRIAC dimmers.
- 3.Please try to use dimmers with power at least 1.5 times as the output power of the driver.




***Using 0-10/1-10V dimming**





Triac/0-10V/1-10V/Potentiometer/10V PWM 5 in 1 Dimmable led driver KVG-DWJ 300W



■ Instruction:

- 1)This driver should be installed by qualified and professional person;
- 2)Please make sure the driver is installed with adequate ventilation around it to allow for heat dissipation.
- 3)Ensure that wiring is correct before test in order to avoid light and power supply damage;
- 4)If driver Cannot work normally, don't maintain privately; Have any question, please contact Zhuhai Shengchang.